



	A	B	C	D	E
PR.1	1	0	0	0	0
PR.2	0	1	0	0	0
PR.3	1	1	0	0	0
PR.4	0	0	1	0	0
PR.5	1	0	1	0	0
PR.6	0	1	1	0	0
PR.7	1	1	1	0	0
PR.8	0	0	0	1	0
PR.9	1	0	0	1	0
PR.10	0	0	0	0	0
PR.11	1	0	0	0	1
PR.12	0	1	0	0	1
PR.13	1	1	0	0	1
PR.14	0	0	1	0	1
PR.15	1	0	1	0	1
PR.16	0	1	1	0	1
PR.17	1	1	1	0	1
PR.18	0	0	0	1	1
PR.19	1	0	0	1	1
PR.20	0	0	0	0	1

DRAWER CASSETTO

